Handset System: in models 1996 -1999.

PWR (power)

Hold this button down for one second to turn the phone on or off. A beep will sound, signaling the power is on.

SND (send)

To make a call, first enter the number then press this button. Also, press this to answer incoming calls.

RCL (recall)

Recalls numbers stored in the memory.

CLR (clear)

Clears the display to ON.

END

Use this button to terminate calls and/or exit phone mode. You may be billed for active phone calls until this button is pressed; however, after 20 seconds of no activity the phone will end the call for you.

OnStar Button

To access subscriber services, press this button to automatically dial the OnStar Center.

STO (store)

Use this button to save numbers in the memory and confirm personalized selections.

Emergency Button

This button automatically dials the OnStar Center for priority emergency services.

FCN (function)

To access many OnStar features, or to enter hands-free voice recognition operation, press this button.